



TO CREATE A
PLANTER OF THE
EXISTING HEXAGON

① REMOVE: PEAS GRAVEL

② SCARIFY BOTTOM TO
1-1½' DEPTH.

③ ADD: 33 cu yds
OF 3 WDT MIX.

PROPOSED
BOULDER

EXISTING
TIMBER
EDGE.

PROPOSED PATHS

PROPOSED
PLANTING
AREAS.

TO
SCHOOL

TO
FENCE

HEXIGON PLANTING BED: NTS.

(OPTIONS)

OCT. 2007

GABRIELE SANTO 519-435-1527

